

(one way removers)

One Way Screw Remover and Installer Sets x One Way Screw Remover and Installer Sets x U.S. Patent # 5450776, ROC, Worldwide Patents Pending. . 2. 3. 4. 5. Loosen set screw. Move up the slide collar to adjust tip depth. Seat tip into one way screw head. Align slide collar flush with surface*. Tighten set screw. Apply steady pressure while removing one way screw. *)

Manufacturers' screws may vary in size. To align collar with surface it may be necessary to hammer the collar onto screw head. For best results slide a short piece of pipe over the shank and tap it gently to seat the collar flush to the surface. The collar must cover the entire screw head to work properly.